




Band Saw Safety Identification




 The band saw can be used for cutting curves, irregular shapes and straight cuts.



Before operating the saw, check to make sure all


guards are in place.



 Check the blade for proper tension and check to make sure the teeth are pointing downward towards the table.

Always use the proper blade that is sharp and in

good condition.



 Only make adjustments while the motor is at a dead stop.


The upper guide assembly should be ½" above the

material.



• Keep your fingers at least 2" away from the side of the blade. Never put your fingers in front of the

blade.




Keep the material flat on the table.



- Before beginning to cut make sure the machine is at full speed.
- Never twist the blade by turning too sharp.


Feed the work into the saw blade at a rate that will

not overload the saw.




 If you have to back out of a long cut shut the machine off and let it come to a complete stop before

backing out.




 Allow the machine to come to a complete stop before leaving the saw.


- Allow the machine to come to a complete stop before leaving the saw.
- Use a stick to clear away scraps from around the blade area, never your hand.



You may tilt the table to cut bevels on the band saw.



Use a V block to cut round stock.



 You may use the miter gage to help you cut miters or to just guide the material as you cut.

